

FIG.1




FIG.2
(PRIOR ART)




FIG.3
(PRIOR ART)




FIG.4 (PRIOR ART)




FIG.5




FIG.6




FIG. 7




FIG.8




FIG. 9




FIG.10




FIG. 11




FIG.12




FIG.13




FIG.14




FIG.15




FIG.16




FIG.17




FIG.18




FIG.19




FIG.20




FIG.21




FIG.22

410:REFERENCE TABLE
FOR PATH SWITCH

The table has two columns: 'ADDRESS.' and 'PORT No.'. The 'ADDRESS.' column lists various addresses starting with '0x0...', and the 'PORT No.' column lists the corresponding port numbers (0, 0, ..., 0, 1, 2, ...). Ellipses are used to indicate intermediate entries and continuation.

ADDRESS.	PORT No.
0x0...000	0
0x0...001	0
⋮	⋮
0x0...OFF	0
0x0...100	1
⋮	⋮
0x0...200	2
⋮	⋮